

Logitech Revue™ with Google TV

Overview

Logitech Revue brings together TV, the full Web, apps, movies and more. If you can think it, you can watch it. Now, your cable and network shows; Web content like YouTube™ videos; music, photos, movie downloads and even apps designed especially for your living room are on your HDTV. Revue makes controlling your entertainment easier, too. The compact keyboard controller lets anyone start searching without a learning curve. Revue works with your existing HDTV, cable or satellite set-top box, AV receiver, even some compatible DVRs. And getting set up couldn't be simpler. Two cables and a broadband Internet connection is all it takes to turn your TV into a smart TV.



- Product Name: Logitech Revue™ with Google TV™
- MSRP: \$299.99
- Available in U.S.A. only
- Target Availability Date: **TBD**
- Warranty: 1 year limited hardware warranty

Specifications


- Intel® Atom™ processor CE41001.2GHz
- Google Android platform (Éclair) on Linux OS

October 2010

- Google Chrome with Flash support
- HDMI input: 1080p/60fps, 1.3a w/ CEC
- HDMI output: 1080p/60fps, 1.3a w/ CEC
- 2.0 USB ports x2
- Networking
- 802.11b/g/n
- RJ45 Network port (Ethernet 10/100)
- 2.5mm IR mini-blasters ports x2
- Memory – 1GB RAM, 4GB Flash
- Built-in Unifying receiver
- 4 IR blasters
- 1 IR receiver

Features

- Integrates TV, Internet, Applications to provide unlimited, searchable access to
- Video content from TV listings
- DVR recordings
- Web-based video sites
- The entire Internet
- Harmony Link integration
- Control your Revue, Set-top box, TV and AV Receiver with the Keyboard Controller
- Harmony for iPhone and Android provides you with control of your Revue, TV, Set-top box and AV Receiver, using your smartphone.
- Control your Revue with a Harmony Remote. Create a Watch Google TV Activity
- The Quick Search Box (QSB) is the central Searching tool for Google TV. It may be accessed from anywhere in the system.



- Enjoy the full Web, including YouTube and Twitter™; apps like Netflix and Logitech Vid™; plus music, photos and games right alongside TV programming.*
- Google Chrome with Flash support
- Video calls from your couch. Your Logitech Revue™ works with specially designed accessories, such as a TV Cam (sold separately) for HD video calling.
- Pre-installed Logitech applications
- Logitech Help Assistant (Interactive troubleshooters, how to and troubleshooting FAQs)
- Logitech Media Player (stream video, music and pictures from other devices on your network)
- Logitech Vid HD (make HD video calls on your TV using the Logitech TV Cam)
- Bundled applications
- Pandora
- Napster
- Twitter
- CNBC
- Amazon On Demand
- NBA Game Time
- Netflix
- [YouTube Leanback](#)
- Google Gallery
- Google Queue

Requirements for Setup & Use

- HDMI compatible TV or monitor, with HDMI input.
- HDMI-compatible digital set-top box or satellite receiver, with HDMI cable.
- Broadband Internet service with a minimum download speed of 1.2 Mbps.

What is included in the box

- Logitech Revue companion box
- Logitech Keyboard Controller
- Power cord
- Power supply
- HDMI cable (1)
- IR mini blaster (1)
- User documentation

Questions & Answers

What is Google TV?

Think of Google TV as television the way it should be — all the things you want to watch, all in one place, right at your fingertips. Google TV is opening up the living room with unlimited content on the TV and enabling people to spend less time finding and more time watching. It turns your TV into a smart TV.

How does Google TV work with Logitech Revue?

The Revue companion box works with the Google TV platform to combine your existing broadcast or pay TV service and Internet access to provide a single interface, single search, and single input device to find, discover, and display your TV content.

While Google TV enables seamless discovery of content, Logitech enables seamless control over how you experience it – by including our Harmony remote control technology into the heart of Google TV and by offering multiple controllers so people have choices in how they interact with Google TV.

What will I need to have Logitech Revue with Google TV at home?

You will need a TV with an HDMI input and a broadband Internet connection. To take full advantage of the content search, you'll need a satellite or cable set-top box with an HDMI output as well. And, for now, you'll need to reside in the United States

When will Logitech Revue with Google TV be available for purchase?

Logitech Revue will be available for purchase on **TBD**.

Where will Logitech's Revue be sold?

Logitech Revue will be available for sale at the following retailers:

- Best Buy
- Amazon.com
- Logitech.com

Why isn't Google TV available outside of the United States?

October 2010

Google TV is mostly relevant in geographies with a high installed base of HD set-top boxes and a high penetration of premium Internet video services. At this time, the U.S. has the largest installed base of HDTVs – at least 60 million.

How much does it cost?

Logitech Revue with Google TV is available for a purchase price of \$299.99 (MSRP).

Can I use the Harmony Remote to control my Revue?

Yes, follow the steps below to control your Revue:

Add the Logitech Revue to your Harmony account.

1. In the Device Type list, select Video Recorder > PVR.
2. In the Manufacturer list, select Logitech.
3. In the Model field, type Revue.

After you have added your Logitech Revue, you must create a Watch TV Activity that uses your Revue.

NOTE: If you already have a Watch TV Activity, you should delete it first.

To set up your Logitech Revue in a Watch TV Activity, log in to your Logitech Harmony Remote Software account and complete the following steps:

1. Click the Activities tab.
2. Click Add Activity.
3. You are asked “Would you like to automatically add Activities that use your devices?” Select Yes – automatically add Activities that use my devices and click Next.
4. Select Watch TV and click Next
5. Select the device do you use to control the volume and click Next.
6. If you are asked which device changes channels, select Logitech Revue and click Next.
7. You are asked to select the inputs used for the devices. Answer the questions and click Next.
8. You are asked to “Review the settings for this Activity”. Select Yes, but I want to add more control of options and devices for this Activity and click Next.
9. Under “Devices Not In Use”, click Add beside your cable/satellite receiver.
10. Click Save.
11. You are asked to select the inputs used for the devices. Answer the questions and click Next.
12. Under “Please review the actions for your Watch TV Activity”, click Save.
13. Under “Review settings for this Activity” select Yes, these setting are correct and click Next.
14. Click Done.
15. Click Update Remote.
16. Ensure your Harmony remote is connected to your computer using the USB cable. Click Next.
17. A page appears showing the progress as your Harmony remote is updated with your device information. The update process could take a few minutes as your Harmony remote is updated with your account information. During the update, do not unplug your Harmony remote unless prompted to do so.
18. Click Next.
19. Unplug your remote and test it.